

Iron On Instructions

Before you begin to iron anything onto your garment, please check what material it is made of. Patches can be ironed onto cotton, cotton blends, velour, denim and wool. For your safety, use a flat surface for ironing on a patch and follow any iron or patch instructions.

Tip: Cotton and polyester fibre blends work the best. Fleece blankets can be ironed on as long as you're careful and use a pressing parchment square or a thin cloth over the patch.

DO NOT apply iron-on patches to waterproof rainwear, rayon, nylon, velvet, acrylic, minky, leather, vinyl, or any other fabrics with finishes, elastics or heat sensitivity. If you're unsure, test with an iron on a hidden seam or hem to see if the fabric accepts the heat without damage.

Hand or machine sewing is recommended to permanently attach patches. The adhesive may not stick well on some fabrics or may peel off over time.



Step By Step Instructions

1. Preheat your iron to 350 degrees Fahrenheit (cotton setting for about five minutes or until hot) and position your patch where you want it on the material.
2. Place a pressing parchment square or a thin cloth over the patch.
TIP: Use a damp cloth when ironing wool or other delicate fabrics. Also, make sure the cloth is damp not soaking wet.
3. Place your iron onto the cloth on top of the patch and apply firm pressure for about 30 seconds.
Allow to cool for five minutes.
4. Next, turn your garment inside-out and iron the area behind the patch while applying firm pressure for 30 seconds. This ensures that the patch is firmly attached. Allow the area to cool for another five minutes and the iron on process is complete.

Additional Tips

- When washing a fabric with iron on patches attached, make sure you turn the garment inside-out.
- Never wash in hot water or dry with heat or you risk loosening the attached patch.
- If your patch is becoming loose you can try to iron it on again, but most likely you will have to sew it on.
- Patches can be sewn onto fabric or garments with a single or double stitch along the border of the patch for extra security.

Disclaimer: Epatches assumes no responsibility for the application of your iron on, damaged fabrics, or any harm sustained while following these instructions and tips.

Epatches

2 Forest Drive Sylvan Lake, Alberta Canada T4S 1H8 Toll Free: 1-877-335-8904

epatches.com